# Quality control systems for compact disc production

# CD-RW/DVD-RW

 thickness and complex refractive index monitoring for the complete layer stack

## DVD

VD substrate thickness anding layer thickness ve layer thickness

# CD-R


- dye-coating processing
- groove geometry in substrate and dye coated surface
- CD-R simulation software


## CD

CD protective layer thickness

CD dishing angle

CD birefringence





ETA-RT measuring system

The measuring table consists of ----

1 ETA-MV-TRO scan table with 1 translatory and 1 rotatory variant

1 ETA-M-R/T R/T measuring head with various reference samples

B ETA-F-R/R optical fibers

The spectrometer unit consists of

- 2 ETA-CS-D256 diod
- 1 ETA-HL-35
- 2 ETA-SD-RW
- 2 ETA-MC-IO
- 1: ETA-P-35

diode lin spectrometers

35\_W halogen light source

stepper-motor drives

microcontroller modules

35 W power supply

The optical measurement system \*\*ETA-RT\*\* is an multifunctional quality control system with high accuracy of m asurement to determine various process relevant parameters in modern compact disc production.

อูลเดาเอาอ่าง oitenotiaa The main tasks of the *ETA-RT* system are: วันสำนักของสายเก็บกับสำคัญ เก็บกับสำคัญ

- CD-RW / DVD-RW layer stack controlling....
- DVD substrate, bonding and semireflectiv layer thickness evaluation leads to refuge the semireflective.
- CD-R dye coating process monitoring and groove geometry determination with a strategy
- CD protective layer thickness, birefringence and dishing angle measurements.

ା ଅନ୍ୟର୍ଗ ପ୍ରାସ**୍ଥର ଜ**ଣ ଜଣ ଅନ୍ଧି

#### System setup: end. It offloate notes than

The *ETA-RT* measuring system is built up strictly modulary so that the user is able to adapt and extend it according to personal as well as future requirements. Depending on customers needs a later enlargement of the *ETA-RT* system can be achieved by registering additional software modules and installing additional hardware components.

The **ETA-RT** basic measuring system is available in two different hardware setups:

- System in 19" table rack for external PC, with spectrometer unit, measuring table and basic spectrometer software (without PC)
- System in 19" tower rack with internal PC, spectrometer unit, measuring table and installed basic spectrometer software

scanning table optical fibers

stepper motor connection

spectrometer unit


## Principle of measurement wasans where and HICIPIE OFFICEASULEMENT TO PER PROPERTY DOTTER AND THE PROPERTY OF THE PROPERT


- high resolution spectral reflectance (R) and transmittance (T) measurement
- automatic referencing


LOCKEY FILL

- measuring rate 100 full spectra 7 sec 3 165 16 3 of T
- user defined measuring and reference : wavelengths (range: 450 ... 1000 nm) (CO) c
- computer controlled scanning table (angular and radial position) adapted to CD-production for complete disc scanning ... v. ........ evecab
- episcanning rate 3 Hz distress is instead CO
- graphical measurement representation (2D, 3D and false color graphs)
- application specific software modules for CD-RW. DVD-RW stack control and DVD, CD-R etc. thickness determination and section a modulary so that a larger is waster

ha ha li khoa i sa wa ku ba i baa ka








statistical data evaluation according to red/ orange book specifications

- iday girrayy, a

interface to STEAG HamaTech machines for inline production control

1.112009



## Data evaluation software modules

Module	Parameter		Resolution	
	<b>R</b> (λ)	Reflectance	0.1 %	
ETA-RT	Τ(λ)	Transmittance	0.1 %	
basic software	Α(λ)	Absorbance		
	$R(\lambda_1)/R(\lambda_2)$	Ratio	·	

## The following additional software modules are available:

Module	Parameter		used spectra	Resolution
CD-R	d, n( $\lambda$ ), κ( $\lambda$ )	CD-R dye layer thickness and material parameters	R and T	± 1 nm
CD-R-SIM		CD-R simulation software		
CD-RW	d, $n(\lambda)$ , $\kappa(\lambda)$	phase change and buffer layer thickness and material parameters	R and T	± 0.5 nm
DVD-ML	d	semireflective layer thickness	RorT	± 0.5 nm
DVD-RW DVD-RAM	d, $n(\lambda)$ , $\kappa(\lambda)$	phase change and buffer layer thickness and material parameters	R and T	± 0.5 nm
CD30	d	CD protective layer thickness	R	± 0.1 µm

## Further extention modules requiring additional hardware components

Module	Parameter		Hardware	Resolution	
DVD80	d	DVD bonding layer thickness	high resolution spectrometer (R)	± 0.1 µm	
DVD600	d	DVD substrate thickness	high resolution spectrometer (T)	± 1.0 µm	
Diffractometer	d, w	groove geometry (depth and width) in substrate and dye coated surface	levelingmeter	± 2.0 nm (d) ± 4.0 nm (w)	
Dishing	α	radial and angular tilt	dishing sensor	± 0.01°	
Birefringence	b	birefringence	birefringence sensor	± 10 nm	

Tel.: +49-Fax: +49-

+49-2452-96001-0 +49-2452-64433